

# TempZone<sup>®</sup> Cable

## Check List

### Materials and Tools Required:

- WarmlyYours TempZone Heating Cable
- Thermostat with Sensor Probe Wire (if applicable)
- Custom Design Layout (provided free with quote)
- Digital Ohm Meter (required for completion of warranty registration card)
- Circuit Check (sold separately)
- Scissors
- Duct Tape or Box Tape (we recommend 3M 6969 Hi-Temp Duct Tape)
- Plastic Notched Trowel
- Self-leveling Cement (for installation with Cable Fixing Strips)
- CeraZorb<sup>®</sup> Concrete Insulating Underlayment (WarmlyYours offers this product for installing floor heating systems over concrete. This is recommended to increase efficiency, but is not mandatory)
- Single Gang Electrical Box/es
- Conduit and Hardware (if required)
- Licensed Electrician
- Available Breaker Box Opening/s for Powering the Floor
- Hot Glue Gun (if using hot glue to secure the Cable Fixing Strips)
- Industrial-grade Hot Glue (if using hot glue to secure the Cable Fixing Strips)
- Staples, Nails, Adhesive, or 1/2" Screws (to attach the Cable Fixing Strips to the subfloor)
- Modified and/or Unmodified Thinset (if installing with the Prodeso Membrane)
- Roller and Plastic Flat Trowel (if installing with the Prodeso Membrane)

## Learn More

Videos, Step by Steps, and Project Guides

[www.WarmlyYours.com](http://www.WarmlyYours.com)

Installation Support • (800) 875-5285